

# GEAR<sup>®</sup> Acrobatic Shock Cords Double Anchor Rigging Sample Diagram

12 ft  
3,6 m

11 ft  
3,35 m

10 ft  
3 m

9 ft  
2,75 m

8 ft  
2,4 m

7 ft  
2,1 m

6 ft  
1,8 m

5 ft  
1,5 m

48"  
122 cm

36"  
91 cm

24"  
61 cm

12"  
30,5 cm

Diagram is intened for demonstration only. Length of cords, hardware and dynamic operation will vary depending upon the configuration and dimensions of a particular venue and preferred user dynamics.

Utilize anchor strapping extensions to lower anchor point to the desired height if needed.

House Anchors  
(not provided)

Carabiners  
shackles can be  
substituted for  
carabiners

Daisy Chains


Position connections  
up or down on Daisy  
Chains to adjust for  
user height

GEAR<sup>®</sup>  
Acrobatic Shock Cords  
static length 21" (53 cm)  
as shown



Insert swivel between  
harness and carabiner  
to facilitate somersaults

GEAR<sup>®</sup>  
Quick Release can be  
inserted at any point  
inline

Use a step or box to  
rig into cords at a  
comfortable height  
above the floor



# Dynamic Stretch



**GEAR**<sub>x</sub>

Acrobatic Shock Cords  
stretched length  
49" (124 cm) as shown  
or 134% dynamic stretch  
Add or remove cords to  
adjust tension

Cord failure at 200%  
stretch or 10' 11" (3,3 m)  
(end loops are non-elastic)